



Graver Technologies

FILTRATION | SEPARATION | PURIFICATION



High Flow RF Series Filter Cartridges

Large Geometry Pleated Filters for High Dirt Loading

Graver High Flow RF Series filter is another in the series of larger geometry filters to handle higher volume applications with fewer filter elements. The result is much faster, easier filter changeouts. In addition, the multi-layer media construction allows for excellent dirt holding capacity, extending the time between filter changeouts. Filter housings are also available and because of the filter's high dirt holding capacity, smaller systems are possible, reducing upfront capital costs.

Product Specifications

Media/Support/Cage: Polypropylene

End Caps: Polypropylene

Gaskets/O-Rings:

Buna-N, EPDM, Silicone,
Teflon Encapsulated Viton

Micron rating:

1, 3, 5, 10, 20, 40, 60, 100 μ m

Dimensions

Nominal length:

39"

(99 cm)

Outside diameter: 6.5" (16.5 cm)

Surface Area:

43 ft² (4.0 m²) per element

Operating Parameters

Maximum operating

temperature: 176°F (80°C)

Maximum differential pressure:

60 psid @ 70°F (4.1 bar @ 21°C)

30 psid @ 176°F (2.0 bar @ 80°C)

Maximum reverse pressure:

25 psid @ 70°F (2.0 bar @ 21°C)

Recommended change-out

pressure: 35 psid (2.4 bar)

Maximum flow rates*:

Up to 80 GPM (132.5 lpm)

*Consult factory for sizing assistance
based on particle loads.

FEATURES & BENEFITS

- 6.5" diameter, large geometry for high flow rates
- Absolute retention ratings from 1 to 100 microns
- Capable of flow rates up to 50 GPM in a single element
- Multi-layer pleated construction with optimized surface area
- Retrofits competitive large diameter filter housings utilizing the "740" design
- Thermally bonded construction
- All polypropylene construction provides for a high level of chemical compatibility

CERTIFICATIONS

- FDA Listed Materials: All materials comply with FDA Title 21 of the Code of Federal Regulations Sections 174.5, and 177.1520, as applicable for food and beverage contact.
- European Directive for Direct Food Contact: European Regulation No. 1935/2004 and European Regulation 10/2011: Tested for migration behavior and is suitable for contact with all kinds of foodstuffs with minimal rinse-up. Pending
- NSF 61: Certified to NSF/ANSI STD 61 for materials requirements only — Component. Pending

TYPICAL APPLICATIONS

- Water Systems
- Refinery Operations
- Wastewater Processes
- Chemicals
- Food and Beverage

HIGH FLOW RF NOMENCLATURE INFORMATION

Product Series	Retention Rating (microns)	Length (inches)	End Configuration	Gasket or O-Ring
HF RF Series	1 20	-40	P2 226/Flat Single Open End	B Buna-N
	3 40			E EPDM
	5 60			S Silicone
	10 100			T Teflon encap. Viton
				V Viton
Example: HF RF 5-40P2E				
HF RF	5	-40	P2	E

HIGH FLOW RF PRESSURE VALUES

Clean Pressure Drop versus Flow at Ambient Temperature — PSID (mbar)

Flow (LPM)	1 μ	3 μ	5 μ	10 μ	20 μ	40 μ	60 μ	100 μ
20 GPM (75.7)	0.6 (41)	0.3 (20)	0.2 (13)	0.2 (13)	0.2 (13)	0.2 (13)	0.2 (13)	0.1 (7)
40 GPM (151.4)	0.9 (62)	0.6 (41)	0.5 (34)	0.5 (34)	0.5 (34)	0.4 (27)	0.4 (27)	0.2 (13)
60 GPM (227.1)	1.6 (110)	1.1 (75)	0.9 (62)	0.9 (62)	0.9 (62)	0.75 (51)	0.75 (51)	0.5 (34)
80 GPM (302.8)	2.2 (151)	1.4 (96)	1.2 (82)	1.2 (82)	1.2 (82)	0.9 (62)	0.9 (62)	0.75 (51)

REMOVAL EFFICIENCY

Beta Ratio Efficiency	Beta 1000 99.9%	Beta 100 99%	Beta 10 90%
1 μm	1.0	0.6	0.2
3 μm	3.0	2.0	1.5
5 μm	5.0	4.0	3.0
10 μm	10.0	8.5	6.5
20 μm	22.0	19.0	14.0
40 μm	38.0	18.0	15.0
60 μm	60.0	35.0	20.0
100 μm	100.0	75.0	45.0

$$\text{Beta Ratio} = \frac{\text{Upstream particle counts}}{\text{Downstream particle counts}}$$

The micron ratings shown at various efficiency and beta ratio value levels were determined through laboratory testing, and can be used as a guide for selecting cartridges and estimating their performance. Under actual field conditions, results may vary somewhat from the values shown due to the variability of filtration parameters.

Testing was conducted using the single-pass test method, water at 3 gpm/10" cartridge. Contaminants included latex beads, coarse and fine test dust. Removal efficiencies were determined using dual laser source particle counters.

FOR MORE INFORMATION

Customer Service/Technical Support: 1-888-353-0303
 Europe (UK): +44-1424-777791 China: +86-21-5238-6576
 Asia: +65-9635-7690

GTX-355 2-17



All information and recommendations appearing in this bulletin concerning the use of products described herein are based on tests believe to be reliable. However, it is the user's responsibility to determine the suitability for his own use of such products. Since the actual use by others is beyond our control, no guarantee, expressed or implied, is made by Graver Technologies as to the effects of such use or the results to be obtained. Graver Technologies assumes no liability arising out of the use by others of such products. Nor is the information herein to be construed as absolutely complete, since additional information may be necessary or desirable when particular or exceptional conditions or circumstances exist or because of applicable laws or government regulations.

DISTRIBUTED BY



Graver Technologies | 200 Lake Drive, Glasgow, DE 19702 | 1-302-731-1700 | 800-249-1990
 Fax: 1-302-369-0938 | info@gravertech.com | www.gravertech.com

A member of The Marmon Group—A Berkshire Hathaway Company